




Ordering spares / Ersatzteil - Regelung / Pièces de rechange / Parti di ricambio / Lista de recambios / Onderdelen bestellen (NL/B) / Κωδικοί Ανταλλακτικών / Bestilling af reservedele / Beställning av reservdelar / Bestilling av reservedeler / Резервни части / Запчасти / Części zapasowe / Piese de schimb / Rendelhető alkatrészek / Запасні частини / Резервни делови / Резервни делови / Atsarginių dalių / Tellitavad varuosad / Rezerves daļas / Náhradní díly / Náhradné diely / Yedek parça siparişi / Nadomestni deli

XX = AA, AD,

- 1 - B 961973 XX
- 2 - B 961951 NU
- 3 - B 961974 XX
- 4 - B 961916 NU
- 5 - A 861399 NU
- 6 - B 961975 NU
- 7 - B 961917 XX
- 8 - A 962574 NU
- 9 - B 960255 NU
- 10 - B 961705 XX


	P	bar		MAX. 10		5			Q	(3 bar)
	T	°C		MAX. 80		65			I/min	3,8




Ideal Standard

CERALIFE O

01.2025 / B565443




B E119 ..












B E100 ..



Ideal Standard International NV
Corporate Village – Gent Building
Da Vincilaan 2
1935 Zaventem
Belgium
<https://www.idealstandard.com>





P	T	°C	4	3	2	1	0
			°C	°C	°C	°C	°C
0,3 MPa 3 bar	50°C	15°C	27	33	41	48	50
	65°C	15°C	33	42	53	63	65
	85°C	15°C	41	53	68	83	85

