







Ordering spares / Ersatzteil - Regelung / Pièces de rechange / Parti di ricambio / Lista de recambios / Onderdelen bestellen (NL/B) / Κωδικοί Ανταλλακτικών / Bestilling af reservedele / Beställning av reservdelar / Bestilling av reservedeler / Резервни части / Запчасти / Części zapasowe / Piese de schimb / Rendelhető alkatrészek / Запасні частини / Резервни делови / Резервни делови / Atsarginių dalių / Tellitavad varuosad / Rezerves daļas / Náhradní díly / Náhradné diely / Yedek parça siparişi / Nadomestni deli

XX = AA, AD,

- | | |
|------------------|------------------|
| 1 - B 961983 XX | 9 - A 964520 NU |
| 2 - B 961951 NU | 9a - B 960255 NU |
| 3 - B 961974 XX | 10 - B 960853 XX |
| 4 - B 961916 NU | 11 - B 961976 AA |
| 5 - A 861399 NU | 12 - A 861421 XX |
| 6 - B 961975 NU | 13 - B 961901 NU |
| 7 - A 861227 XX | |
| 7a - B 961917 XX | |
| 8 - A 962574 NU | |




B E120 ..




Ideal Standard

CERALIFE O


01.2025 / B565444



B E110 ..



B E111 ..



B E112 ..



Ideal Standard International NV
Corporate Village – Gent Building
Da Vincilaan 2
1935 Zaventem
Belgium
<https://www.idealstandard.com>



