




Ordering spares / Ersatzteil - Regelung / Pièces de rechange / Parti di ricambio / Lista de recambios / Onderdelen bestellen (NL/B) / Κωδικοί Ανταλλακτικών / Bestilling af reservedele / Beställning av reservdelar / Bestilling av reservedeler / Резервни части / Запчасти / Części zapasowe / Pieśe de schimb / Rendelhető alkatrészek / Запасні частини / Резервни делови / Резервни делови / Atsarginių dalių / Tellitavad varuosad / Rezerves daļas / Náhradní díly / Náhradné diely / Yedek parça siparişi / Nadomestni deli

XX = AA, AD,

- 1 - B 961734 XX
- 2 - B 960473 XX
- 3 - B 961677 XX
- 4 - A 861397 NU
- 5 - B 960712 XX
- 6 - B961676 NU
- 7 - A 860984 NU
- 8 - B 960255 NU
- 9 - A 963600 NU
- 10 - B 964682 NU
- 11 - A 960911 NU
- 12 - B 961738 XX
- 13 - B 961739 XX
- 14 - B 960465 XX
- 15 - B 961346 NU
- 16 - A 962630 NU




CERAPLAN



Ideal Standard

07.2021 / B565177

B D330 ..



Ideal Standard International NV
Corporate Village – Gent Building
Da Vincilaan 2
1935 Zaventem
Belgium
<http://www.idealstandardinternational.com>



