

101..M 006..70



104 105 106 007..70

103..M 001..

101..70 100..



103..70 102..

101..-16




COMPATIBILITY:

- ELY
- TA
- TI
- RO
- LEA
- EL/EF
- BR
- BI
- LIG
- RIN/WS
- CA
- SK
- GR
- RED
- JO
- JK




Montaggio
Assembly


1




$65 \pm 5^\circ\text{C}$




$15 \pm 5^\circ\text{C}$



MIN - MAX



OK




G 1/2"



G 1/2"



101..M
104 105 106
103..M
101..70
103..70
101..-16






006..70



007..70

2
a



101
103







Installazione corpi
Bodies installation



Fissaggio Bocche
Spout Fixing




b





Installazione corpi
Bodies installation




b 1



Fissaggio Bocche
Spout Fixing




c





Installazione corpi
Bodies installation

c1




Fissaggio Bocche
Spout Fixing







a




b




c




d




e



f.1





f.2




F

Funzionamento
Working




4




006..70

007..70




Fissaggio Leve Fixing Levers



M

Manutenzione Service








Sostituzione Deviatore
How to replace Diverter



001

a



CH24

CH2,5






ELY

CH24

CH2,5

b
Sostituzione Cartuccia
How to replace Cartridge



c
Sostituzione Aeratore
How to replace Aerator